

Software Update for SRT 7300CI

The following manual describes the procedure for a software update at your receiver via your PC and portable USB storage device.

Hardware Requirements:

- Windows PC or other operating system with USB or USB 2.0 port. Other systems might require different procedures.
- External USB device

Note: Please check/ensure that the power consumption of your USB device is not higher than 5V/500 mA. In case the power consumption is higher, please connect the USB device to a corresponding power adapter before connecting to your receiver, otherwise the usage of such an USB device could damage your receiver.

Procedure at PC:

1. Save the zipped file in a folder of your choice. Unpack the files to this folder (right mouse click: "Unpack here..." or double click -> select "Unpack to", then choose the corresponding folder to save the files).
2. Connect your USB device to the USB port on your PC. Usually your PC shows a message that a new hardware is found/connected (removable disk).
3. Copy the software files of the "SRT7300_v2.24" folder into the ROOT directory of the connected USB device (please do not copy the folder, just copy the software files inside this folder!).
4. Afterwards please remove the USB device from your PC by pressing the right mouse button at the task bar to "Safely remove hardware" in order to avoid any problems.

Procedure at Receiver:

Switch ON your receiver and connect the USB device with the stored software to the connector at the receiver. After the USB device has been detected successfully, you can perform the software update according to the following steps.

1. Press the **MENU** button to enter Main Menu. Select *Advanced* with the ◀▶ buttons and choose *USB Update* with the ▲▼ buttons then press **OK** to enter the menu.
2. Within the *USB Update* menu the message "USB Device is ready" will be displayed. Then use the **RED** button on your remote control to perform the *Upgrade*. The Software Upgrade progress will be shown. PLEASE wait until this process is finished!

NEVER disconnect the USB device from the receiver, the receiver from the main or switch the power OFF during the update procedure. It can damage your receiver and warranty will void! As soon as the update has been finished, the receiver restarts automatically!