

Software Update for SRT 7002

The following manual describes the procedure for a software update at your receiver via your PC and portable USB storage device.

Hardware Requirements:

- Windows PC or other operating system with USB or USB 2.0 port. Other systems might require different procedures.
- External USB storage device

Note: Please check/ensure that the power consumption of your USB device is not higher than 5V/500 mA. In case the power consumption is higher, please connect the USB device to a corresponding power adapter before connecting to your receiver, otherwise the usage of such an USB device could damage your receiver.

Procedure at PC:

1. Save the zipped file in a folder of your choice. Unpack the files to this folder (right mouse click: "Unpack here..." or double click -> select "Unpack to", then choose the corresponding folder to save the files).
2. Connect your USB device to the USB port on your PC. Usually your PC shows a message that a new hardware is found/connected (removable disk).
3. Copy the .AP file into the ROOT directory of the connected USB device.
4. Afterwards please remove the USB device from your PC by pressing the right mouse button at the task bar to "Safely remove hardware" in order to avoid any problems.

Procedure at Receiver:

Switch ON your receiver and connect the USB device with the stored software to the connector at the receiver. After the USB device has been detected successfully, you can perform the software update according to the following steps.

1. Press the **MENU** button to enter Main Menu. Select *System* with the ◀▶ buttons and choose *Software Update* with the ▲▼ buttons then press **OK** to enter the menu.
2. Within the *Software Update* menu use the ▲▼ buttons to select *By USB* and press **OK** to enter the menu.
3. The ROOT directory with the contained .AP file will be displayed. There select the correct file with the ▲▼ buttons and press **OK** to proceed. Confirm the displayed message with **OK** to start the Update process. The Software Update progress will be shown. PLEASE wait until this process is finished!
4. Once the Software Update process has been finished the message: "Software Upgrade complete. Please restart" will be shown. Push the power button on the front panel to restart the receiver.

NEVER disconnect the USB device from the receiver, the receiver from the main or switch the power OFF during the update procedure. It can damage your receiver and warranty will void!